

K3IM5AACL20

Monitoring relays - KAPPA series Multifunction 2 change over contacts Plug-in housing Width 38mm



Read and understand these instructions before installing, operating or maintaining the equipment.



Danger! Never carry out work on live parts! Danger of fatal injury! The product must not be used in case of obvious damage. To be installed by an authorized person.

Technical data

1. Functions

a.c. current monitoring in 1-phase mains with adjustable thresholds, timing for start-up suppression and tripping delay seperatly adjustable and the following functions, which are selected by means of rotary switch:

OVER	Overcurrent monitoring
UNDER	Undercurrent monitoring
WIN	Monitoring the window between Min and Max
OVER+Latch	Overcurrent monitoring with fault latch
UNDER+Latch	Undercurrent monitoring with fault latch
WIN+Latch	Monitoring the window between Min and Max with fault latch

A divistment renge

2. Time ranges

	Aujustin	enitranye
Start-up suppression time (Start):	0	10s
Tripping delay (Delay):	0.1	10s

3. Indicators

Green LED U/t ON/OFF:	indication of supply voltage
Green LED U/t flashes:	indication of start-up suppression time
Red LED Min/Max ON/OFF:	indication of failure of the corresponding
	threshold
Red LED Min/Max flashes:	indication of tripping delay of the
	corresponding threshold
Yellow LED ON/OFF:	indication of relay output

4. Mechanical design

Self-extinguishing plastic housing, IP rating IP40 Mounted on screw terminal socket 11-pols in accordance with IEC 60067-1-18a (type R11X or PF113BE/M) Mounting position: any Sockproof terminal connection according to VBG 4 (PZ1 required),

5. Input circuit

Supply voltage: Pins: Tolerance: Rated consumption: Rated frequency: Duration of operation: Reset time: Wave form: Hold-up time: Drop-out voltage: Overvoltage category: Rated surge voltage: 230V a.c. S2-S10 / A1-A2 -15% to +10% of U_N 8VA (1W) a.c. 48 to 63Hz 100% 500ms Sinus ->20% of supply voltage

III (in accordance with IEC 60664-1) 4kV

6. Output circuit

2 potential free change over contactsRated voltage:250V a.Switching capacity:1250VAFusing:5A fastMechanical life:20 x 10°Electrical life:2 x 10°at 1000

Switching frequency:

Overvoltage category: Rated surge voltage:

7. Measuring circuit

Measuring variable: Measuring input: Pins: Overload capacity: Starting current: 1s 3s Input resistance: Switching threshold I_s:

Overvoltage category: Rated surge voltage:

8. Accuracy Base accuracy:

Adjustment accuracy: Repetition accuracy: Voltage influence: Temperature influence:

9. Ambient conditions

Ambient temperature: Storage temperature: Transport temperature: Relative humidity:

Pollution degree:

ontacts 250V a.c. 1250VA (5A / 250V) 5A fast acting 20 x 10⁶ operations 2 x 10⁵ operations at 1000VA resistive load max. 6/min at 1000VA resistive load (in accordance with IEC 60947-5-1) III (in accordance with IEC 60664-1) 4kV

a.c. Sinus, 48 to 63Hz 5A a.c. (galvanically seperated) S5-S7 / i-k 10A

100A 50A < 10m Ω see table ordering information or printing on the unit III (in accordance with IEC 60664-1) 4kV

±5% of nominal value ±5% of nominal value ≤2% of nominal value

0.05% / °C

-25 to +55°C -25 to +70°C -25 to +70°C 15% to 85% (in accordance with IEC 60721-3-3 class 3K3) 2 (in accordance with IEC 60664-1)

K3IM5AACL20

Functions

Overcurrent monitoring (OVER, OVER+Latch)

When the supply voltage U is applied, the output relay R switches into on-position and the set interval of the start-up suppression (Start) begins. Changes of the measured current during this period do not affect the state of the output relay R.

When the measured current exceeds the Max-value, the output relay R switches into off-position after the interval of the tripping delay (Delay) has expired.

OVER:

The output relay R switches into on-position again, if the current falls below the Min-value.

OVER+Latch:

The output relay R switches only into on-position again by interrupting and re-applying of the supply voltage and a new measuring cycle begins with the set interval of the start-up suppression time (Start).



Window function (WIN, WIN+Latch)

When the supply voltage U is applied, the output relay R switches into on-position and the set interval of the start-up suppression (Start) begins. Changes of the measured current during this period do not affect the state of the output relay R.

When the measured current leaves the window between Min and Max, the output relay R switches into off-position after the interval of the tripping delay (Delay) has expired.

WIN:

The output relay R switches into on-position again, if the current re-enter the adjusted window.

WIN+Latch:

The output relay R switches only into on-position again by interrupting and re-applying of the supply voltage and a new measuring cycle begins with the set interval of the start-up suppression time (Start).



Under current monitoring (UNDER, UNDER+Latch)

When the supply voltage U is applied, the output relay R switches into on-position and the set interval of the start-up suppression (Start) begins. Changes of the measured current during this period do not affect the state of the output relay R.

When the measured current falls below the Min-value, the output relay R switches into off-position after the interval of the tripping delay (Delay) has expired.

UNDER:

The output relay R switches into on-position again, if the current exceeds the Max-value.

UNDER+Latch:

The output relay R switches only into on-position again by interrupting and re-applying of the supply voltage and a new measuring cycle begins with the set interval of the start-up suppression time (Start).



Connections



D '		
Dim	ens	ions
	0110	10110



Ordering information

Туре	Rated voltage $U_{_N}$	Functions	Switching thresholds ${\rm I}_{\rm s}$	Start-up suppression time (Start)	Tripping delay (Delay)	Part. No.
K3IM5AACL20	230V a.c.	O, U, W, O+L, U+L, W+L	Max: 10% to 100% of I _N Min: 5% to 95% of I _N	0s to 10s	0,1s bis 10s	1380202

RELEASE 2013/06

Subject to alterations and errors

